

SQF Complex Fire

Alternative Fire Debris Removal Program Road Map

TULARE COUNTY EMERGENCY SERVICES

Note:

Property Owners that choose to opt out of the Consolidated Debris Removal must adhere to the following:

- Required to remediate the property and remove burn debris at their own expense.
- Comply with all applicable requirements.
- Do so in a timely manner.
- Property owners will not be reimbursed with public funds.
- Work must be completed in a manner that ensures protection of public health and safety.



Step 1

Property Owners opting out of Consolidated Debris Removal Program

- Must submit Alternative Fire Debris Removal Program Application to Tulare County Environmental Health.
- Must submit Work Plan (Appendix E).
- Must submit demolition permit (RMA).
- Underground Service Alert (USA) notification/permit (if necessary).
- Application must be submitted 2 weeks prior to commencing debris removal.

Step 2

Beginning of work

- Work can begin as soon as permits listed above are issued and work plan is approved.
- Background site assessment (Site testing and analysis plan) (Per Workplan).
- Hazardous waste and asbestos removal (Appendix D).
- Debris removal/disposal/recycling (Appendix C).
- Soil grading and erosion control (Appendix A).

Step 3

After implementation of approved work plan

Submission of certification that all work was completed as specified to include the following:

- Confirmation Soil Sampling conducted by qualified environmental consultant (Appendix F).
- Transport and Disposal documentation for generated debris disposal/recycling (Appendix A).
- Submission of Final report and Property Owner Certification and Indemnification (Appendix B & F).

